



NEEDLE SHIM INSTALL
INSTRUCTIONS
REVISED 1/6/2022



USE A GOOD PHILLIPS SCREW DRIVER TO REMOVE SCREWS. (SCREWS WILL BE TIGHT)

MAKE SURE DIAPHRAM IS LOCATED IN GROOVE PROPER AND NOT PINCHED.
TIP: SMALL AMOUNT OF LIGHT GREASE WILL HELP HOLD DIAPHRAM



USING 6MM SOCKET OR NEEDLE NOSE PLIERS PUSH DOWN AND TURN PLASTIC NUT TO REMOVE NEEDLE

INSTALL WASHERS AS SHOWN.
BE CAREFUL NOT TO LOSE SPRING.

