

# BELT DRIVE STARTER KIT

REVISED 7/7/14

## KIT CONTENTS:

QUANTITY 1 SHAFT, PART NUMBER 8139-19

QUANTITY 2 BEARING, PART NUMBER SB402-12

QUANTITY 4 BEARING BRACKET, PART NUMBER BRH47MST-ZP

QUANTITY 2 LOCKING COLLAR, PART NUMBER 8560

QUANTITY 1 SHAFT KEY

THIS KIT WAS DESIGNED TO GIVE YOU THE BASIC HARDWARE TO SET YOUR SLED UP FOR THE BELT DRIVE, THE LOCATION OF THE SHAFT AND BEARINGS SHOULD BE **CAREFULLY** THOUGHT OUT BEFORE DRILLING OR CUTTING ANY HOLES IN THE BULKHEAD OF YOUR SLED, NOT DOING THIS COULD LEAD TO CRACKING OR BREAKAGE OF THE BULK HEAD.

WHEN PRESSING THE BEARINGS INTO THE BEARING BRACKET, MAKE SURE TO PRESS ONLY ON THE OUTSIDE DIAMETER OF THE BEARINGS TO KEEP FROM DAMAGING THE BEARING, THE BRACKETS HAVE NO HOLES DRILLED IN THEM; THIS IS TO ALLOW YOU TO PLACE THEM WHERE YOU WANT. ALWAYS REMEMBER TO PUT THE LOCKING COLLARS ON THE BEARING SIDE OF THE BRACKET TO KEEP BEARINGS IN PLACE.

TECH LINE (319) 462-6932 MONDAY 8 AM TO 5PM, TUESDAY AND WEDNESDAY 8 AM TO NOON CST.

\*\*\*\*\*PLEASE NOTE\*\*\*\*\*

**This product is intended for closed-course racing only and is sold “as-is” without warranty. Manufacturer and distributor specifically disclaim all responsibility for consequential and incidental damages or any other losses arising from the use of this product. Any dispute arising out of the use of this product must be settled in Linn County, Iowa under Iowa law.**

\*\*\*\*\*