

ADJUSTABLE CLUTCH INSTRUCTIONS FOR JR SHOCKWAVE CLUTCH (8/8/18)

Our new clutch cover is designed to allow you to make quick and easy spring preload adjustments. By increasing the preload you will raise the engagement and shift RPMs. This allows you to fine tune your clutching for different track conditions.

1.) We have supplied a small amount of dry graphite lubricant to be used on the cover bushing and shaft. We suggest you apply it with a rubber glove or rag.



2.) Each mark on the clutch cover will increase the spring preload by .020 up to .060 total. By adding the additional supplied .020 washers you can add more preload.



3.) Using the supplied tool, push the center hub and rotate to the desired preload. **NOTE: Make sure that the hub locks into the cover completely. More pressure will be needed when using a stiffer spring.**



IMPORTANT ALWAYS CHECK FOR SPRING COIL BIND OR CLUTCH DAMAGE WILL OCCUR!

*****PLEASE NOTE*****

This product is intended for closed-course racing only and is sold "as-is" without warranty. Manufacturer and distributor specifically disclaim all responsibility for consequential and incidental damages or any other losses arising from the use of this product. Any dispute arising out of the use of this product must be settled in Linn County, Iowa under Iowa law.
